

## NEX Xen Topaz Daylight Savings Time Fast Track Instructions

***Important note:*** Please leave the handset sitting in its cradle while you are pressing keys to make the time or date change.

1. Change the time is from the main phone
2. Press the Speaker key on the phone's handset while the receiver is in its cradle
3. Press 828
4. Enter the new time using the 24 hour clock format
5. Press the Speaker key to record your changes

